

Equipos Compatibles con Procard

Marca	Modelo	Sistema Operativo	Compatible Procard
Acer	CloudMobile S500	Android	✓
Acer	Liquid E1	Android	✓
Acer	Liquid Express E320 *	Android	✓
Acer	Liquid Glow E330 *	Android	✓
Acer	Liquid S2	Android	✓
Alcatel	1x	Android	✓
Alcatel	3 / 3L	Android	✓
Alcatel	5 / 5V	Android	✓
Alcatel	A7	Android	✓
Alcatel	Idol 3	Android	✓
Alcatel	Idol 4, 4S	Android	✓
Apple	iPhone 6 / 6 Plus **	iOS	x
Apple	iPhone 6S / 6S Plus **	iOS	x
Apple	iPhone SE (all version)**	iOS	✓
Apple	iPhone 7 / 7 Plus **	iOS	✓
Apple	iPhone 8 / 8 Plus **	iOS	✓
Apple	iPhone X **	iOS	✓
Apple	iPhone Xs / Xs Max **	iOS	✓
Apple	iPhone Xr **	iOS	✓
Apple	iPhone 11 (all version)	iOS	✓
Apple	iPhone 12 (all version)	iOS	✓
Apple	iPhone 13 (all version)	iOS	✓
Apple	iPhone 14 (all version)	iOS	✓
Apple	iPhone 15 (all version)	iOS	✓
Apple	iPhone 16 (all version)	iOS	✓
Asus	5s	Android	✓
Asus	Padfone 2	Android	✓
Asus	Padfone Infinity	Android	✓
Asus	ROG Phone	Android	✓
Asus	ROG Phone 2	Android	✓
Asus	ROG Phone 3 / 3 strix	Android	✓
Asus	ROG Phone 5 / 5 Pro / 5s Pro / 5 Ultimate	Android	✓
Asus	ROG Phone 6 / 6 Pro / 6D / 6D Ultimate	Android	✓
Asus	ROG Phone 7	Android	✓
Asus	Snapdragon Insiders	Android	✓
Asus	Zenfone 2	Android	✓
Asus	Zenfone 4	Android	✓
Asus	Zenfone 5 / Lite / 5Z	Android	✓
Asus	Zenfone 6	Android	✓
Asus	Zenfone 7 / 7 Pro	Android	✓
Asus	Zenfone 8 / 8 Flip	Android	✓
Asus	Zenfone 9	Android	✓
Asus	Zenfone 10	Android	✓
Asus	Zenfone Max Pro (M2)	Android	✓
Blackberry	Bold 9790 *	Blackberry OS	✓
Blackberry	Bold 9900	Blackberry OS	✓
Blackberry	Bold 9930	Blackberry OS	✓

Marca	Modelo	Sistema Operativo	Compatible Procard
Blackberry	Classic	Blackberry 10	✓
Blackberry	Curve 9350	Blackberry OS	✓
Blackberry	Curve 9360	Blackberry OS	✓
Blackberry	Curve 9370	Blackberry OS	✓
Blackberry	Curve 9380	Blackberry OS	✓
Blackberry	DTEK60	Android	✓
Blackberry	Key2 / 2 LE	Android	✓
Blackberry	KEYone	Android	✓
Blackberry	P'9982 Porsche Design	Blackberry 10	✓
Blackberry	P'9983	Blackberry 10	✓
Blackberry	Passport	Blackberry 10	✓
Blackberry	PRIVt	Blackberry 10	✓
Blackberry	Q5	Blackberry 10	✓
Blackberry	Q10	Blackberry 10	✓
Blackberry	Z10	Blackberry 10	✓
Blackberry	Z30	Blackberry 10	✓
Google	Galaxy Nexus	Android	✓
Google	Nexus 10	Android	✓
Google	Nexus 4	Android	✓
Google	Nexus 5	Android	✓
Google	memory Nexus 5X	Android	✓
Google	Nexus 6	Android	✓
Google	memory Nexus 6P	Android	✓
Google	Nexus 7 (2012) / (2013)	Android	✓
Google	Nexus 9	Android	✓
Google	Nexus S	Android	✓
Google	Pixel / XL	Android	✓
Google	Pixel 2 / XL	Android	✓
Google	Pixel 3 / XL / 3a / 3a XL	Android	✓
Google	Pixel 4 / XL	Android	✓
Honor	8 / 8 Pro	Android	✓
Honor	9 / 9A	Android	✓
Honor	9X / Lite / Pro	Android	✓
Honor	memory 10 / 10x Max /10 x Lite	Android	✓
Honor	20 / 20 Pro	Android	✓
Honor	30 / 30i / 30 Pro / 30 Pro Plus / 30 Lite youth	Android	✓
Honor	50 / 50 Lite / 50 Pro	Android	✓
Honor	60 / 60 Pro	Android	✓
Honor	70 / Lite	Android	✓
Honor	90	Android	✓
Honor	Magic	Android	✓
Honor	Magic 2	Android	✓
Honor	Magic 3 / Pro / Pro Plus	Android	✓
Honor	Magic 4 / Pro / Lite / Ultimate	Android	✓
Honor	Magic V/ Pro / Lite	Android	✓
Honor	tablet_android Note 10	Android	✓
Honor	Play 4 Pro	Android	✓
Honor	Play 5	Android	✓
Honor	V9	Android	✓

Marca	Modelo	Sistema Operativo	Compatible Procard
Honor	V10 /V10 Lite	Android	✓
Honor	V30 / V30 Pro	Android	✓
Honor	V40 / V40 Lite	Android	✓
Honor	View 20	Android	✓
Honor	X6a	Android	✓
Honor	x8 / x8a / x8 5G	Android	✓
Honor	X9 / X9 5g	Android	✓
Honor	X10 Max	Android	✓
Honor	X30 Max	Android	✓
HTC	8X	Windows Phone	✓
HTC	10 / 10 Evo	Android	✓
HTC	Amaze 4G	Android	✓
HTC	Desire 12s	Android	✓
HTC	Desire 19 Plus / 19s	Android	✓
HTC	Desire 20 Plus / 20 Pro	Android	✓
HTC	Desire 21 Pro 5G	Android	✓
HTC	Desire 22 Pro	Android	✓
HTC	Desire 530	Android	✓
HTC	Desire 610	Android	✓
HTC	Desire 620 *	Android	✓
HTC	Desire 620G	Android	✓
HTC	Desire 816	Android	✓
HTC	Desire 820	Android	✓
HTC	Desire C	Android	✓
HTC	Desire Eye	Android	✓
HTC	Evo 4G LTE	Android	✓
HTC	First	Android	✓
HTC	J Butterfly	Android	✓
HTC	One	Android	✓
HTC	One A9	Android	✓
HTC	One M8	Android	✓
HTC	One M8 for Windows	Windows Phone	✓
HTC	One M9 / M9+	Android	✓
HTC	One Max	Android	✓
HTC	One Mini 2	Android	✓
HTC	One SV	Android	✓
HTC	One VX	Android	✓
HTC	One X / X+	Android	✓
HTC	One X10	Android	✓
HTC	One XL	Android	✓
HTC	U11 / Life / Eyes / Plus	Android	✓
HTC	U12 Life / Plus	Android	✓
HTC	U19e	Android	✓
HTC	U20	Android	✓
HTC	U23 Pro	Android	✓
Huawei	Ascend G6	Android	✓
Huawei	Ascend Mate 7	Android	✓
Huawei	Ascend P2	Android	✓
Huawei	Ascend P7	Android	✓

Marca	Modelo	Sistema Operativo	Compatible Procard
Huawei	Ascend P7-L10 (Europe version)	Android	✓
Huawei	Ascend W1	Windows Phone	✓
Huawei	G8	Android	✓
Huawei	Mate 8	Android	✓
Huawei	Mate 9	Android	✓
Huawei	Mate 10 / 10 Pro	Android	✓
Huawei	Mate 20 / 20X / Pro / Lite	Android	✓
Huawei	Mate 30 / 30 RS / 30 Pro / 30E Pro	Android	✓
Huawei	Mate 40 / 40 RS / 40 Pro / Pro plus / 40 Pro 4G	Android	✓
Huawei	Mate 40E / 40E 4G	Android	✓
Huawei	Mate 50 / 50 RS / 50 Pro	Android	✓
Huawei	Mate S / Mate XS	Android	✓
Huawei	Mate X2 / Mate X2 4G	Android	✓
Huawei	Nexus 6P	Android	✓
Huawei	Nova 5T	Android	✓
Huawei	Nova 6	Android	✓
Huawei	Nova 7 Pro	Android	✓
Huawei	Nova 8 / 8i / 8 Pro	Android	✓
Huawei	Nova 9 / 9 Pro / SE	Android	✓
Huawei	Nova 10 / 10 SE	Android	✓
Huawei	Nova Y90	Android	✓
Huawei	nova Young	Android	✓
Huawei	P Nova Lite 3 Plus	Android	✓
Huawei	P Nova 7 / 7 Pro	Android	✓
Huawei	P smart / smart S	Android	✓
Huawei	memory P smart 2019	Android	✓
Huawei	P Smart Plus / Smart Z / Smart S / Smart 2020	Android	✓
Huawei	P8 / Lite 2017	Android	✓
Huawei	P9 / Plus / Lite	Android	✓
Huawei	P10 / Plus	Android	✓
Huawei	memory P10 Lite	Android	✓
Huawei	P20 / Pro	Android	✓
Huawei	P30 Pro / Lite / P30 Pro New Edition	Android	✓
Huawei	P40 / P40 Pro / Pro Plus / Lite / 4G / 5G	Android	✓
Huawei	P50 / P50 Pro / Pocket / P50E	Android	✓
Huawei	Watch 2	Android	✓
Huawei	Y8P	Android	✓
Lenovo	Legion Y70 / Y90	Android	✓
Lenovo	Legion Phone Duel / Duel 2	Android	✓
Lenovo	Lemon K10 Note	Android	✓
Lenovo	Lemon K12 Pro	Android	✓
Lenovo	Lemon K13 Note	Android	✓
Lenovo	P2	Android	✓
Lenovo	tablet_android ThinkPad X1 Carbon *	Windows 10	✓
Lenovo	tablet_android ThinkPad X1 Yoga *	Windows 10	✓
Lenovo	tablet_android ThinkPad X380 Yoga *	Windows 10	✓
Lenovo	ThinkPhone	Android	✓
Lenovo	Z 5 Pro GT	Android	✓
Lenovo	Z 6 Pro	Android	✓

Marca	Modelo	Sistema Operativo	Compatible Procard
LG	Escape	Android	✓
LG	G Flex 2	Android	✓
LG	G2 / Mini LTE	Android	✓
LG	G3 D855 / G3 S	Android	✓
LG	G4 (H815)	Android	✓
LG	G5 / G5 SE	Android	✓
LG	memory G6 (H870)	Android	✓
LG	G7 Fit / One / ThinQ	Android	✓
LG	G8/G8s/G8X ThinQ	Android	✓
LG	K10	Android	✓
LG	K10 2018	Android	✓
LG	K10 Alpha 2018	Android	✓
LG	K10 Plus 2018	Android	✓
LG	K30 2019	Android	✓
LG	K40 / 40s	Android	✓
LG	K50s	Android	✓
LG	K51s	Android	✓
LG	K52	Android	✓
LG	K61	Android	✓
LG	K62	Android	✓
LG	K92	Android	✓
LG	L Fino	Android	✓
LG	L50	Android	✓
LG	Leon 4G	Android	✓
LG	Nexus 5X	Android	✓
LG	Optimus 4X HD	Android	✓
LG	Optimus L5 / L5 II	Android	✓
LG	Optimus L7 II	Android	✓
LG	Optimus L9 II	Android	✓
LG	Optimus Vu *	Android	✓
LG	Optimus Vu 2	Android	✓
LG	Power X	Android	✓
LG	Prada 3.0	Android	✓
LG	Q Stylus	Android	✓
LG	Q6 / Alpha / Plus	Android	✓
LG	Q7 / Alpha / Plus	Android	✓
LG	Q8	Android	✓
LG	Q9	Android	✓
LG	Q31	Android	✓
LG	Q51	Android	✓
LG	Q51	Android	✓
LG	Q52	Android	✓
LG	Q61	Android	✓
LG	Q70	Android	✓
LG	Q92	Android	✓
LG	Spectrum 2	Android	✓
LG	Velvet / 5G	Android	✓
LG	V10	Android	✓
LG	V30	Android	✓

Marca	Modelo	Sistema Operativo	Compatible Procard
LG	V30 ThinQ / V30s ThinQ	Android	✓
LG	V35 ThinQ	Android	✓
LG	V40 ThinQ	Android	✓
LG	V50 ThinQ 5G	Android	✓
LG	V50S ThinQ	Android	✓
LG	V60 ThinQ 5G	Android	✓
LG	Wing	Android	✓
LG	X screen	Android	✓
LG	X venture	Android	✓
Meizu	16s / 16s Pro	Android	✓
Meizu	17 / 17 Pro	Android	✓
Meizu	18 / 18 Pro	Android	✓
Meizu	18s / 18s Pro	Android	✓
Meizu	Pro 6	Android	✓
Microsoft	Surface Duo 2	Android	✓
Motorola	Defy	Android	✓
Motorola	Droid Razr i	Android	✓
Motorola	Droid Razr Maxx / HD	Android	✓
Motorola	Edge / Edge Plus / Edge S	Android	✓
Motorola	Edge 20 / Lite / Pro / Fusion	Android	✓
Motorola	Edge 30 Pro	Android	✓
Motorola	Edge 40 / 40 Pro / 40 Neo	Android	✓
Motorola	Edge 2021	Android	✓
Motorola	Moto E4 / Plus	Android	✓
Motorola	Moto E13	Android	✓
Motorola	Moto Edge 30 / X30 / 30 Fusion / 30 Ultra / 30 Neo	Android	✓
Motorola	Moto G 2014 / G Pro / G 100 / G 5G / G Play / G Stylus	Android	✓
Motorola	memory Moto G5S Plus	Android	✓
Motorola	Moto G7 / Plus	Android	✓
Motorola	Moto G8 Plus	Android	✓
Motorola	Moto G9 Plus / Power / Play	Android	✓
Motorola	Moto G10 / G20 / G30 / G31 / G40 Fusion / G41 / G50 / G51 / G60 / G60s / G71 / G71s	Android	✓
Motorola	Moto G13/ G22 / G23 / G32 / G42 / G52 / G53 / G54 / G62 / G72 / G73 / G82	Android	✓
Motorola	Moto G100	Android	✓
Motorola	Moto G200 5G	Android	✓
Motorola	Moto Razr	Android	✓
Motorola	Moto S30	Android	✓
Motorola	Moto Maxx	Android	✓
Motorola	Moto X / X Play	Android	✓
Motorola	Moto X30 / X40	Android	✓
Motorola	Moto Z2 Force / Z2 Play	Android	✓
Motorola	Moto Z3 Play Power Edition	Android	✓
Motorola	Moto Z4	Android	✓
Motorola	Nexus 6	Android	✓
Motorola	One Hyper	Android	✓
Motorola	One Vision / Plus	Android	✓
Motorola	One Zoom / Action	Android	✓
Motorola	Photon Q	Android	✓
Motorola	Razr 2019 / 5G	Android	✓

Marca	Modelo	Sistema Operativo	Compatible Procard
Motorola	Z4	Android	✓
Nokia	2.2	Android	✓
Nokia	3 / 3.1 / 3.1 Plus / 3.4	Android	✓
Nokia	4.2	Android	✓
Nokia	5 / 5.1 / 5.3 / 5.4	Android	✓
Nokia	memory 6 / 6.1 / 6.2	Android	✓
Nokia	7 / 7.1 / 7 Plus	Android	✓
Nokia	memory 8 / 8.1 / 8 Sirocco / 8.3	Android	✓
Nokia	9 PureView	Android	✓
Nokia	603	Symbian	✓
Nokia	6131	Nokia OS	✓
Nokia	6212 Classic	Nokia OS	✓
Nokia	6216 Classic	Nokia OS	✓
Nokia	700	Symbian	✓
Nokia	701	Symbian	✓
Nokia	808 PureView	Symbian	✓
Nokia	C7	Symbian	✓
Nokia	G11 / G20 / G22 / G50 / G60 / G300	Symbian	✓
Nokia	Lumia 1020	Windows Phone	✓
Nokia	Lumia 1520	Windows Phone	✓
Nokia	Lumia 2520	Windows Phone	✓
Nokia	Lumia 610 NFC Version	Windows Phone	✓
Nokia	Lumia 620 NFC Version	Windows Phone	✓
Nokia	Lumia 640 / XL / LTE	Windows Phone	✓
Nokia	Lumia 650	Windows Phone	✓
Nokia	Lumia 720	Windows Phone	✓
Nokia	Lumia 730	Windows Phone	✓
Nokia	Lumia 735	Windows Phone	✓
Nokia	Lumia 810	Windows Phone	✓
Nokia	Lumia 820	Windows Phone	✓
Nokia	Lumia 822	Windows Phone	✓
Nokia	Lumia 830	Windows Phone	✓
Nokia	Lumia 920	Windows Phone	✓
Nokia	Lumia 925	Windows Phone	✓
Nokia	Lumia 928	Windows Phone	✓
Nokia	Lumia 930	Windows Phone	✓
Nokia	Lumia 950 / XL	Windows Phone	✓
Nokia	Lumia Icon	Windows Phone	✓
Nokia	N9	MeeGo	✓
Nokia	X10 / X20 / X30 / XR20 / XR21 / X100	MeeGo	✓
Nubia	Play	Android	✓
Nubia	Red Magic 5S / 5G lite / 5GAndroid	Android	✓
Nubia	Red Magic 6 / 6 Pro / 6R	Android	✓
Nubia	Red Magic 7 / 7s / Pro	Android	✓
Nubia	Red Magic 8 Pro / Pro Plus	Android	✓
Nubia	Z30 Pro	Android	✓
Nubia	Z40s Pro	Android	✓
Nubia	Z50	Android	✓
OnePlus	One	Android	✓

Marca	Modelo	Sistema Operativo	Compatible Procard
OnePlus	3 / 3T	Android	✓
OnePlus	5 / 5T	Android	✓
OnePlus	6 / 6T	Android	✓
OnePlus	7 / 7 Pro / 7 T	Android	✓
Oppo	A1 Pro	Android	✓
Oppo	A5 2020	Android	✓
Oppo	A7n	Android	✓
Oppo	A9 2020	Android	✓
Oppo	A16s	Android	✓
Oppo	A54 / A57s	Android	✓
Oppo	A72 / A74 /A74 5G / A77 / A77s / A77 5G / A78/ A78 4G	Android	✓
Oppo	A91	Android	✓
Oppo	A92s	Android	✓
Oppo	A94 / 5G	Android	✓
Oppo	A98	Android	✓
Oppo	Ace 2	Android	✓
Oppo	Find N	Android	✓
Oppo	F23	Android	✓
Oppo	Find N2 / N2 Flip	Android	✓
Oppo	Find X	Android	✓
Oppo	Find X2 / Find X2 Pro / Find X2 Lite / Find X2 Neo	Android	✓
Oppo	Find X3 Pro / X3 Neo / Lite	Android	✓
Oppo	Find X5 / Lite / Pro	Android	✓
Oppo	K5	Android	✓
Oppo	K7	Android	✓
Oppo	K10 Pro / K10 5G	Android	✓
Oppo	N3	Android	✓
Oppo	Reno / Ace / 5G / Z / 10x Zoom	Android	✓
Oppo	Reno2	Android	✓
Oppo	Reno3 / Reno 3A / Reno3 Vitality / Reno3 Pro	Android	✓
Oppo	Reno4 / Reno4 Pro / 4z	Android	✓
Oppo	Reno 5 A	Android	✓
Oppo	Reno 6 Pro / 5G / Pro Plus	Android	✓
Oppo	Reno 7 / Z / Pro / Lite / A	Android	✓
Oppo	Reno 8 / Z / T / 5G / Pro / Lite / Pro Plus	Android	✓
Oppo	Reno 9 / Pro / Pro Plus	Android	✓
Oppo	Reno 10	Android	✓
Oppo	RX17 Pro	Android	✓
Oppo	X2 Neo / X2 Lite	Android	✓
Poco	X3	Android	✓
Realme	7, 5G, Pro, x7 Pro, x7 Pro Ultra	Android	✓
Realme	8 / Pro / 5G	Android	✓
Realme	9 Pro Plus	Android	✓
Realme	10 Pro Plus	Android	✓
Realme	11 Pro / Plus / 5G	Android	✓
Realme	C51	Android	✓
Realme	GT / GT NEO / GT NEO2 / GT NEO2T / GT NEO3 / GT Master / GT Master Explorer / GT Neo 5	Android	✓
Realme	GT2 / GT2 Pro / GT2 Master Explore	Android	✓
Realme	GT3	Android	✓



Marca	Modelo	Sistema Operativo	Compatible Procard
Realme	GT5 / GT5 240W	Android	✓
Realme	Narzo 30	Android	✓
Realme	XT	Android	✓
Realme	X2,Pro	Android	✓
Realme	X3,Super	Android	✓
Realme	X7 Max	Android	✓
Realme	X50, Pro, m, 5G	Android	✓
Samsung	Ativ S	Windows Phone	✓
Samsung	Galaxy A3 2017 ***	Android 8.0	✓
Samsung	Galaxy A5 2017 ***	Android 8.0	✓
Samsung	Galaxy A6 / A6 Plus	Android	✓
Samsung	Galaxy A7 / A7 2018	Android	✓
Samsung	Galaxy A8 / A8 2018 / A8 Plus 2018	Android	✓
Samsung	Galaxy A8s	Android	✓
Samsung	Galaxy A13 5G	Android	✓
Samsung	Galaxy A14	Android	✓
Samsung	Galaxy A20e	Android	✓
Samsung	Galaxy A24	Android	✓
Samsung	Galaxy A30s / A31	Android	✓
Samsung	Galaxy A33	Android	✓
Samsung	Galaxy A34	Android	✓
Samsung	memory Galaxy A40	Android	✓
Samsung	Galaxy A41	Android	✓
Samsung	Galaxy A42	Android	✓
Samsung	Galaxy A50 / 50s	Android	✓
Samsung	Galaxy A51 / A51 5G	Android	✓
Samsung	Galaxy A52 / A52 5G	Android	✓
Samsung	Galaxy A53	Android	✓
Samsung	Galaxy A54	Android	✓
Samsung	Galaxy A60	Android	✓
Samsung	Galaxy A70 / A70s	Android	✓
Samsung	Galaxy A71 / A71 5G	Android	✓
Samsung	Galaxy A72	Android	✓
Samsung	Galaxy A73 5G	Android	✓
Samsung	Galaxy A80	Android	✓
Samsung	Galaxy A90	Android	✓
Samsung	Galaxy Ace 3	Android	✓
Samsung	Galaxy Ace 4	Android	✓
Samsung	Galaxy Alpha	Android	✓
Samsung	Galaxy A Quantum / Quantum 2 / Quantum 3	Android	✓
Samsung	Galaxy Core 2	Android	✓
Samsung	Galaxy Core Advance / Plus / Prime	Android	✓
Samsung	Galaxy Express 2	Android	✓
Samsung	Galaxy F33	Android	✓
Samsung	Galaxy F14	Android	✓
Samsung	Galaxy F23	Android	✓
Samsung	Galaxy F34	Android	✓
Samsung	Galaxy F54	Android	✓
Samsung	Galaxy F62	Android	✓

Marca	Modelo	Sistema Operativo	Compatible Procard
Samsung	Galaxy Fame / Lite	Android	✓
Samsung	Galaxy Grand Duos / Prime	Android	✓
Samsung	Galaxy J3 (2016)	Android	✓
Samsung	Galaxy J4 Plus	Android	✓
Samsung	memory Galaxy J5 (2016) / (2017)	Android	✓
Samsung	Galaxy J5 Pro	Android	✓
Samsung	Galaxy J6 Plus	Android	✓
Samsung	Galaxy J7 (2017)	Android	✓
Samsung	Galaxy K Zoom	Android	✓
Samsung	Galaxy M14	Android	✓
Samsung	Galaxy M21 / M22	Android	✓
Samsung	Galaxy M30s	Android	✓
Samsung	Galaxy M31 / M32 / M34	Android	✓
Samsung	Galaxy M51 / M52 5G / M53 5G / M54	Android	✓
Samsung	Galaxy M62	Android	✓
Samsung	Galaxy M	Android	✓
Samsung	Galaxy Mega	Android	✓
Samsung	Galaxy Mini 2	Android	✓
Samsung	Galaxy Nexus	Android	✓
Samsung	Galaxy Note 2	Android	✓
Samsung	Galaxy Note 3 / Neo	Android	✓
Samsung	Galaxy Note 4	Android	✓
Samsung	Galaxy Note 5	Android	✓
Samsung	Galaxy Note 7 / 7 FE	Android	✓
Samsung	Galaxy Note 8	Android	✓
Samsung	Galaxy Note 9	Android	✓
Samsung	memory Galaxy Note 10 / 10+	Android	✓
Samsung	Galaxy Note 20 / 20 Ultra	Android	✓
Samsung	Galaxy Note Edge	Android	✓
Samsung	Galaxy S2 *	Android	✓
Samsung	Galaxy S3 / S3 Neo	Android	✓
Samsung	Galaxy S3 Mini *	Android	✓
Samsung	Galaxy S4 / S4 Active / S4 Mini / S4 Zoom	Android	✓
Samsung	memory Galaxy S5	Android	✓
Samsung	Galaxy S5 Mini	Android	✓
Samsung	Galaxy S6 / S6 Edge / S6 Edge Plus	Android	✓
Samsung	memory Galaxy S7 ***	Android 8	✓
Samsung	Galaxy S7 Edge	Android	✓
Samsung	memory Galaxy S8 ***	Android 8	✓
Samsung	Galaxy S8+	Android	✓
Samsung	memory Galaxy S9	Android	✓
Samsung	Galaxy S9 Plus	Android	✓
Samsung	Galaxy S10 / S10 Plus / S10e	Android	✓
Samsung	Galaxy S20	Android	✓
Samsung	Galaxy S21 (all version)	Android	✓
Samsung	Galaxy S22 (all version)	Android	✓
Samsung	Galaxy S23 (all version)	Android	✓
Samsung	Galaxy Superior	Android	✓
Samsung	tablet_androidmemory Galaxy Tab Active / Pro	Android	✓

Marca	Modelo	Sistema Operativo	Compatible Procard
Samsung	tablet_androidmemory Galaxy Tab Active2	Android	✓
Samsung	Galaxy Xcover 3 (G388F) / (G389F)	Android	✓
Samsung	Galaxy Xcover 4	Android	✓
Samsung	Galaxy Xcover 4s	Android	✓
Samsung	Galaxy XCover FieldPro	Android	✓
Samsung	Galaxy Young	Android	✓
Samsung	Galaxy Z Flip (all verison)	Android	✓
Samsung	Galaxy Z Fold (all version)	Android	✓
Samsung	W2019	Android	✓
Samsung	W21	Android	✓
Samsung	Wave 578	Bada	✓
Sharp	Aquos D10	Android	✓
Sharp	Aquos Sense3 / Plus	Android	✓
Sharp	Aquos Zero2 / 5G Basic DX	Android	✓
Sony	SmartWatch 2	Android	✓
Sony	Xperia 1 / 1 II / 1 III / 1 IV / 1 V	Android	✓
Sony	Xperia 5 / Pro / 5 II / 5 III / 5 IV / 5 V	Android	✓
Sony	Xperia 8 / 8 Lite	Android	✓
Sony	Xperia 10 / 10 Lite /10 Plus / 10 II / 10 III / 10 III Lite/ 10 IV / 10 V	Android	✓
Sony	Xperia Pro-I	Android	✓
Sony	Xperia Ace II	Android	✓
Sony	Xperia Acro S	Android	✓
Sony	Xperia C4	Android	✓
Sony	Xperia C5 Ultra	Android	✓
Sony	Xperia Ion	Android	✓
Sony	Xperia L	Android	✓
Sony	Xperia L2	Android	✓
Sony	Xperia L3	Android	✓
Sony	Xperia L4	Android	✓
Sony	Xperia M / Dual	Android	✓
Sony	Xperia M2 / Aqua	Android	✓
Sony	Xperia M4 Aqua	Android	✓
Sony	Xperia M5	Android	✓
Sony	Xperia P	Android	✓
Sony	Xperia Pro / S / SL / Sola / SP	Android	✓
Sony	Xperia T	Android	✓
Sony	Xperia T3	Android	✓
Sony	Xperia Tablet Z	Android	✓
Sony	Xperia TX	Android	✓
Sony	Xperia V	Android	✓
Sony	Xperia X / Performance / Compact	Android	✓
Sony	Xperia XA1 Plus / XA1 Ultra	Android	✓
Sony	Xperia XA2 / Plus / Ultra	Android	✓
Sony	Xperia XZ / XZs / XZ2	Android	✓
Sony	memory Xperia XZ Premium	Android	✓
Sony	Xperia XZ1 / XZ1 Compact	Android	✓
Sony	Xperia XZ3	Android	✓
Sony	Xperia Z / Ultra	Android	✓
Sony	Xperia Z1 / Compact	Android	✓

Marca	Modelo	Sistema Operativo	Compatible Procard
Sony	Xperia Z2 / Tablet	Android	✓
Sony	Xperia Z3 / Compact / Plus / Z3+	Android	✓
Sony	tablet_android Xperia Z4 Tablet	Android	✓
Sony	Xperia Z5 Compact / Z5 Premium	Android	✓
Sony	Xperia ZL	Android	✓
Stonex	Stonex One	Android	✓
Sunmi	tablet_android M2 Max	Android	✓
TCL	10 Plus / SE	Android	✓
Turkcell	T11	Android	✓
Turkcell	T40	Android	✓
VIVO	X51 5G	Android	✓
Wiko	T60	Android	✓
Wiko	Wim Lite	Android	✓
Wiko	View 2 / Go / Pro / Plus	Android	✓
Wiko	View 3 Pro	Android	✓
Xiaomi	11 Lite / 11T / 11 T Pro / 11i Hypercharge	Android	✓
Xiaomi	12 / 12x / 12Pro / 12T / 12T Pro / 12 Lite / 12s / 12s Pro / 12s Ultra	Android	✓
Xiaomi	13 / 13 Pro / 13T /13 Ultra / Lite	Android	✓
Xiaomi	14 / 14 Pro	Android	✓
Xiaomi	Black Shark 4 / 4 Pro / 4s / 4s Pro	Android	✓
Xiaomi	Black Shark 5 / Rs / Pro	Android	✓
Xiaomi	Civi / 1S / Civi 2 / Civi 3	Android	✓
Xiaomi	MI 2a	Android	✓
Xiaomi	Mi 3	Android	✓
Xiaomi	Mi 4	Android	✓
Xiaomi	memory Mi 5 / 5s / 5s Plus / 5X	Android	✓
Xiaomi	Mi 6	Android	✓
Xiaomi	Mi 8	Android	✓
Xiaomi	Mi 9T	Android	✓
Xiaomi	Mi 10 (All Version)	Android	✓
Xiaomi	Mi 11 (All Version)	Android	✓
Xiaomi	Mi CC9 Pro	Android	✓
Xiaomi	Mi Mix / Mi Mix Fold	Android	✓
Xiaomi	Mi Mix 2 / 2S	Android	✓
Xiaomi	Mi Mix 3	Android	✓
Xiaomi	Mi Mix 4	Android	✓
Xiaomi	Mi Fold 2	Android	✓
Xiaomi	Mi Note 2	Android	✓
Xiaomi	Mi Note 3	Android	✓
Xiaomi	Mi Note 10 / Lite / Pro	Android	✓
Xiaomi	Mix Fold 3	Android	✓
Xiaomi	Redmi 10X Pro	Android	✓
Xiaomi	Redmi K20	Android	✓
Xiaomi	Redmi K30 / Ultra	Android	✓
Xiaomi	Redmi Note 8T	Android	✓
Xiaomi	Redmi Note 9 / Pro	Android	✓
ZTE	Axon 7 / Mini	Android	✓
ZTE	Axon 9 Pro	Android	✓
ZTE	Axon 10s Pro 5G	Android	✓

Marca	Modelo	Sistema Operativo	Compatible Procard
ZTE	Axon 11 5G	Android	✓
ZTE	Axon 20 / 20 Pro 5G	Android	✓
ZTE	Axon 30 / 30s / 30 Pro 5G / 30 Ultra	Android	✓
ZTE	Axon 40 SE / 40 Pro / 40 Pro Plus / 40 Ultra	Android	✓
ZTE	Axon 50 Ultra	Android	✓
ZTE	Axon M	Android	✓
ZTE	Blade A3 2020	Android	✓
ZTE	Blade A7	Android	✓
ZTE	Blade A31 / Plus / Ultra	Android	✓
ZTE	Blade A41 / Ultra / Ultra Extreme	Android	✓
ZTE	Blade A52	Android	✓
ZTE	Blade A71	Android	✓
ZTE	Blade A73	Android	✓
ZTE	Blade V9	Android	✓
ZTE	Blade V10 / 10	Android	✓
ZTE	Blade V40 / V40s / V40 design	Android	✓
ZTE	Blade V41 Vita	Android	✓
ZTE	Blade V50 Design	Android	✓
ZTE	Blade V2020 / smart	Android	✓
ZTE	Blade X1	Android	✓
ZTE	Grand	Android	✓
ZTE	V70	Android	✓
ZTE	Zmax Pro	Android	✓

Actualizado a enero 13 de 2025

\* La compatibilidad NFC solo está disponible en algunas versiones de este modelo. Se aconseja consultar el manual de instrucciones o ponerse en contacto con la oficina central.

\*\* El iPhone 7 y versiones posteriores pueden leer y escribir etiquetas NFC, pero deben actualizarse a iOS 13. Para obtener más información, visite [apple.com](https://apple.com)

La lista se actualiza constantemente de acuerdo con las especificaciones declaradas por los productores. Animamos a los usuarios a informar sobre cualquier dato que no sea correcto. Procard no asume ninguna responsabilidad por cualquier inexactitud.

Las marcas mencionadas en este documento pertenecen a sus respectivos propietarios.